

## Casement Sash Adjustment



Use this adjustment for a window frame that has been installed slightly out of square and requires a minor readjustment.

Severely out-of-square openings may require partial or complete reinstallation.

### Step 1

From the outside, note the reveal of the leading edge of the casement sash as it fits to the edge of its frame. Determine the direction in which the bottom of the sash should be moved to better align it.

### Step 2

Open the casement sash and expose the crank mechanism.

### Step 3

Insert a casement wrench into position as shown in the image above. The bottom of the sash will be moved as far as  $\frac{1}{4}$ " either way, depending upon the direction of the wrench rotation.

### Step 4

Crank the sash closed and engage the lock. If any binding occurs, repeat previous steps.